


POWER HEAD GROUP



Be Sure to Specify Model and Serial Number of Motor When Ordering Parts

PHOTO AND PART NUMBERS FOR POWER HEAD GROUP

Photo No.	Part No.	Name of Part	Photo No.	Part No.	Name of Part
1	120110	Lock Ring	24	303473	Clamp
2	303333	Wrist Pin	25	303439	Gasket
3	376067	Piston and Dowel Pin Assembly (376070 Piston and Connect- ing Rod Assembly, with Rings)	26	303407	Exhaust Cover
4	376066	Connecting Rod Assembly	27	25-74	Screw
5	41-17	Lockplate	28	303468	Lever
6	41-44	Screw	29	303109	Bearing Clamp
7	304109	Crankshaft	30	132123	Screw
8	41-333	Piston Ring	31	43-156	Screw
9	120395	Key	32	132346	Screw
10	303649	Oil Slinger	33	300154	Washer
11	510168	Cam	34	300454	Grommet
12	51-47	Screw	35	300455	Anchor
13	303467	Gasket	36	41-223	Screw
14	376229	Cylinder and Crankcase Assembly	37	303278	Support
15	203235	Leaf Valve	38	203319	Dowel
16	203248	Plate	39	303277	Retaining Ring
17	19-191	Screw	40	27-309	Core Plug
18	41-178	Screw	41	303438	Gasket
19	300399	Washer	42	376080	Cylinder Head and Core Plug Assembly
20	51-47	Screw	43	27-309	Core Plug
21	300402	Taper Pin	44	43-302	Washer
22	71-1084	Screw	45	303459	Screw
23	303463	Hose	46	*200322	Spark Plug (Cham- pion J6J)
			46	*376290	Spark Plug (Auto - Lite A3X)
			47	303236	Spring

***WE RECOMMEND EITHER CHAMPION OR AUTO-LITE SPARK PLUGS**

Order All Parts from Nearest Service Station or Dealer